

Installation Guide

SYSTEM SET UP ITEMS

- > 1x **A)** LUMIRANK 12V Power **Cable** (M12 green Plug open wire)
- > 1x **B)** MyLaps **X2** RaceLink with RF Antenna & GPS Antenna
- > 1x **C)** LUMIRANK LED **Position Display**
- > 1x **D)** STS / LUMIRANK **Driver Info Display** V20 Voice
- > 1x **E)** ML M8 Y ext. **Cable** (Female / Male / Female)
- > 1x **F)** SAS M8 / DTM / DEUTSCH / Log. Connetion **Cable** (for X2 RaceLink **PRO only**)

A)



B)



C)




D)



E)



F)



Connection INFO

SYSTEM Connection

- A)** LUMIRANK 12V Power Cable > connect to MAIN VDD (on during PitStop)
- B)** MyLaps X2 RaceLink > Antenna needs to be mounted on the roof !
- C)** LUMIRANK Position Display > Please see Install Guidelines and Series Instructions
- D)** STS / LUMIRANK Driver Info Display > Must be visible to the driver - connect to M8 Y
- E)** ML M8 Y Cable (Female / Male / Female) > connect LR & DID & X2 RacLink
- F)** SAS M8/DTM/ DEUTSCH / Logger > use only on X2Pro and for Logger connection.

